

TECHNICAL SPECIFICATIONS

UPHOLSTERED CURTAINS



1 CURTAIN / 4 INSTALLATION METHODS

1 - INSTALLATION ON A ROD INSERTED INTO THE SLEEVE

- Pass the rod through the sleeve across the entire width of the curtain
- Spread out the fabric and adjust the pleats using the gathering cord to ensure an even drape

> Quick installation, clean and neat finish, ideal for exposed curtain rods



2 - INSTALLATION ON RAIL WITH RAIL PASS-THROUGH

- Pass the rod through the fabric loops
- Spread the fabric and adjust the folds for an even drape

> Quick installation, simple and sleek finish



3 - RAIL MOUNTING

- Place the clips on the top of the curtain, spacing them according to the width of the curtain rods (10 clips per curtain panel).
- Adjust the height according to your wall rail.
- Attach the hooks to the rail sliders.

> Compatible with all rails, perfect pleat retention



4 - INSTALLATION ON RAIL WITH RINGS

- Place the clips on the top of the curtain, spacing them according to the width of the curtain rods (10 clips per curtain panel).
- Thread the hooks through the rings and pinch them together so that the two small loops overlap. (10 hooks and 10 rings per curtain panel).
- Insert the small loops of the hook into the clip.

> Compatible with all curtain rods, easy to install and handle

